

# Accord Leather Shift Knob Installation

HandA-Accessories.com



1. With parking brake applied and foot on brake, pull shifter back to the #1 position and remove the 2 screws with a Phillips screwdriver.



2. Pull upward on shift knob to remove it from the shift shaft.



3. Grasp knob and shaft tube, pull apart - small tabs inside shaft tube will break, so just dispose of the original shaft tube



4. Using a small, flat blade screwdriver, pry side cover from original shift knob and pop it off of the knob - the tabs inside cover will break, dispose of cover.



5. Remove button and spring from original knob - NOTE ORIENTATION of the spring- it is slightly offset.



6. Get new leather knob and look inside to locate spring pin



7. Insert button and spring into leather knob so spring slides down over the pin- DON'T WORRY if button does not pop out by itself - it will, once installed.



8. Get new side cover and align it onto side of knob



**9.** Press the cover securely in place



**10.** Get new shaft tube and slide it onto the bottom of knob so the 2 holes line up



**11.** Install shaft tube over shift shaft so the threaded screw holes line up.



**12.** Insert screws and tighten snugly - top screw will sink in further than bottom screw as shown