


HandA-Accessories.com

Locking Gas Cap Instructions.

With the key in the lock cylinder insert cylinder with the brass tab facing towards the notched area in the cap. Press lock cylinder straight into cap.



Section of gas cap has been brightened to show detail better in the picture, gas caps are not metal.