


2004 ODYSSEY - Wireless Headphone Battery Replacement

1. Remove the battery covers (A) from the wireless headphone by inserting a coin in the locktabs (B) and lifting the covers.
2. Remove the batteries (C) from the wireless headphone.

Replacement Battery Size: AAA



3. Push the on/off button (A), and confirm that the indicator (B) comes on after the batteries are replaced.

