



INSTALLATION INSTRUCTIONS


Accessory
ROOF RAILS
P/N 08L02-SZA-100A

Application
2012 PILOT


Publications No.
All 46396
Issue Date
AUG 2011

PARTS LIST


Left roof rail



Right roof rail



Left front roof rail cover



Right front roof rail cover




Left rear roof rail cover




Right rear roof rail cover



8 Torx nuts



4 Roof molding clips



TOOLS AND SUPPLIES REQUIRED

Phillips screwdriver

Flat-tip screwdriver

Shop towel

Needle nose pliers

T-30 Torx driver

Tape measure

File

Drill

3 mm and 10 mm Drill bits


Pushpin

Eye protection (face shield, safety goggles, etc.)

The following tools are available through the Honda Tool and Equipment Program. On the iN, click on: Service > Service Bay > Tool and Equipment Program, then enter the number under "Search". Or, call 888-424-6857.

- Air saw (Snap-on AT192A)
- Plastic trim tool (T/N SILTRIMTL10)

Illustration of the Roof Rails Installed on the Vehicle



INSTALLATION


Customer Information: The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by “do-it-yourselfers.”

NOTE:


- The weight of the cargo must not exceed the maximum weight capacity of 75 kg (165 lbs).
- Be extremely careful not to damage the roof and other finished surfaces of the body when installing the roof rails.

Installing the Roof Rails


1. Open the tailgate. Using a plastic trim tool, pry up on the rear end of the left roof molding cover.



2. Using a pushpin, pierce two holes at the scribe marks on the left roof molding cover.




3. While wearing eye protection, drill two holes in the left roof molding cover with a 3 mm drill bit at the pierced marks made in step 2.




4. Enlarge the two holes with a 10 mm drill bit. Remove any burrs.


5. While wearing eye protection, use an air saw to cut the left roof molding cover along the scribe line as shown. Remove any burrs.




6. Remove the left roof molding by carefully lifting it upward from the four vehicle roof molding clips.




7. Remove and discard the four vehicle roof molding clips from the left roof molding or the stud bolt.




8. Remove any excess sealant from the stud bolts.




9. While wearing eye protection, use an air saw to cut the roof molding at the measurements shown.




10. Install one new roof molding clip to each roof molding.




11. Reinstall the roof molding left cover.



12. Reinstall the roof moldings back into the left roof channel using the two new roof molding clips installed in step 10.




13. Install the left roof rail with four Torx nuts. Make sure the roof rail is installed in the correct position. Torque the Torx nuts to 12 N·m (9 lbf·ft).



14. Repeat steps 1 through 13 for the right side of the vehicle.

15. Install the left front roof rail cover and the left rear roof rail cover to the left roof rail (two clips for each cover).



16. Install the right roof rail covers the same way.